







HS802




HS803

The HS80 Series is a compact, pistol-grip design two-button, three-button with Emergency stop pendant station, and features:


- An especially ergonomic design-less than three inches wide-weighing only 10 ounces
- Construction of high impact ABS, and high visibility safety yellow
- NEMA 4 waterproof rating
- Single-speed 5 amp, 250 volt contact block
- Multi-diameter cable bushing







HS802



HS803





















SWITCHES

TYPE	APPEARANCE	CONTACT ARRAGEMENT	OPERATION
N80B		N80B 10  N80B 11 	MAINTAINED ON-OFF SUPPLIED WITH RED & GREEN BOOT.
N80C		N80C 20  N80C 22 	MOMENTARY SINGLE-SPEED WITH MECHANICAL INTERLOCKING
N80J		N80J 11  N80J 20  N80J 22 	MOMENTARY SINGLE-SPEED OR MOMENTARY ON-OFF NON-INTERLOCKED SUPPLIED WITH RED & GREEN BOOT.
N80D		N80D 40  N80D 44 	MOMENTARY 2-SPEED WITH MECHANICAL INTERLOCKING
N80T		N80T 40  N80T 44 	MOMENTARY DUAL POLE MECHANICAL INTERLOCKING
N80R-2(V)		RED LAMP (V)=Volatage (D12)-12VDC LED (D24)-24VDC LED (110)-110VAC NEON (220)-220VAC NEON	PLOT LAMP SMALL (12mm hole) RED For use in 6, 8, 10 button enclosures only.
CA-12N B80R-9(V)			



ITEM NO.	
HS821	Emergency stop switch, (Reset) Illuminated push off-push on switch 2 Single speed UP, Down (↑ . ↓) Deep back
HS822	Emergency stop switch, (Reset) Illuminated push off-push on switch 2 Double speed UP, Down (↑ ↑ . ↓ ↓) Deep back



ITEM NO.	
HS831	Emergency stop switch, (Reset) Selector switch 2 position, 1-2 4 Single speed
HS832	Emergency stop switch, (Reset) Selector switch 2 position, 1-2 4 Double speed
HS833	Emergency stop switch, (Reset) Illuminated push off-push on switch 4 Single speed Deep back
HS834	Emergency stop switch, (Reset) Illuminate push off-push on switch 4 Double speed Deep back



ITEM NO.	
HS841	Emergency stop switch, (Reset) Selector switch 2 position, 1-2 6 Single speed
HS842	Emergency stop switch, (Reset) Selector switch 2 position, 1-2 6 Double speed
HS843	Emergency stop switch, (Reset) Pilot lamp 6 Single speed
HS844	Emergency stop switch, (Reset) Pilot lamp 6 Double speed



ITEM NO.	
HS851	Emergency stop switch, (Reset) Pilot lamp 6 Single speed 2 Double speed
HS852	Emergency stop switch, (Reset) Pilot lamp 4 Single speed 4 Double speed
HS861	Emergency stop switch, (Reset) Selector switch 2 position, 1-2 6 Single speed 4 Double speed
HS862	Emergency stop switch, (Reset) Selector switch 2 position, 1-2 4 Single speed 6 Double speed